

The Rolladeck system has many different ways to adjust the tool to the specific needs of the respective vehicle. Included are examples of how to determine what settings are needed.

## 1. Selecting Base Plate

Begin by selecting the appropriate base plate that fits the wiper post. If the bore on the base plate is too large for the post, the spline of the post will protrude through the bore such as these examples in figures A and E.



Figure A



Figure E

If the base plate fits correctly, only the threads of the post will protrude. See figure B and F.



Figure B



Figure F

Once the appropriate base plate has been selected, you may secure it with the existing wiper post nut. Each base plate is designed to be setup conventionally but can be reversed if necessary for clearance. See figure 1 and 2. If the base plate will not clear the cowl valley, it may be necessary to reverse the base plate.



Figure 1



Figure 2

## 2. Selecting Slide Plate

Select the appropriate slide plate of the 4 plates in your kit. This is done by measurement or by sight. Slide the slide plate over the base plate. Set screws and check the distance to the windshield at rest. This example that we've selected is too large for clearance in the cowl valley. See figure C.



Figure C

It would be necessary to select the next size down for clearance. This will be a good time to determine if a drop down setting is necessary. Measure between the slide plate and the windshield at rest in the opening. If there is less than 1 1/2 inches, then a conventional setting is necessary. See figure 3. If there is more than 1 1/2 inches between the slide and the windshield, a single drop is necessary. See figure G.



Figure 3



Figure G

If there is more than 2 1/2 inches between the windshield and the slide, then a double drop is necessary. See figure H and I and 4 for single drop down configuration. See figure 5 for double drop down configuration.



Figure H



Figure I



Figure 4



Figure 5



If the distance between the post and the glass is less than 1 1/2 inches it may be necessary to preassemble the Rolladeck and install all components as one.

### **3. Adjusting Rolladeck to the windshields**

Once the appropriate setup is determined, proceed by cutting the windshield free along the bottom and the sides, leaving the top attached. Lift the windshield at the bottom then, slide the roller platform up under the windshield then lock the set screws. See figure J.



Figure J

If you need further assistance, please call our technical support line at 941.467.0790.

You can also find helpful demonstration videos on numerous vehicles on our YouTube channel at [www.youtube.com/c/RolladeckNetRolladeckWindshieldSettingSystem](http://www.youtube.com/c/RolladeckNetRolladeckWindshieldSettingSystem) or scan the QR code to go directly to our channel.

